Nue Skin 50 plus Microdermabrasion THINGS to Try Before You Call

Things to LOOK for:



black hoses are the outside ports

insert clear hose here - clear hoses are the inside ports



POOR SUCTION

Inserting Hand Piece in Correct Ports -

- Insert "Red or Blue" hand piece tubing in the correct ports - when facing the machine (Right side - Crystals)
 - a. Black tube is inserted in the outside port.
 - b. Clear tube is inserted in the inside port.
 - c. Incorrect tube location will cause harm to machine.
- Insert "Yellow" hand piece tubing in the correct ports - when facing the machine (Left side - Organic Grains)
 - a. Black tube is inserted in the outside port.
 - b. Clear tube is inserted in the inside port.
 - c. Incorrect tube location will cause harm to machine.

Hand Pieces -

- Check O-rings due to wear and tear
 O-rings may have cracks or worn areas.
 Replace if necessary.
- Hand piece tubing check for a secure fit from the hand piece to the tubing. Adhesive may wear over time. Make sure the tubing is tight and secure to the hand piece. May use "Super Glue" around the outside mouth of the hose(s) and reinsert to secure the fit of the tube.





Clear hose - inserted in the hole that is more centered. If tubing becomes dislodge from a hand piece you must insert tubing into the correct hole. If not, the flow of crystals or grains and vacuum may be redirected to the wrong canisters and may harm the machine.

- Black hose is inserted in the hole that is closer to the wall of the hand piece.
- Clear hose is inserted into the hole that is more centered.

POOR SUCTION

Bottle Stoppers -	
•	Worn bottle stoppers may cause air
	leaks, causing less suction.
•	Check the base of the bottle stopper
	and make sure it is flat to the surface
	when closed.
•	If the yellow rim is becoming gray and
	loose then it is time to replace.
•	You can visually check for wear.
Carrietore	
	anisters -
	Eventually the threads on the canisters
	will wear over time.
•	Most likely it will be the waste canister
	that will wear out.
•	If plastic threads look frayed and worn,
	you will need to order new.
•	Worn canister may cause air leaks
	which would cause poor suction.

Nue Skin 50 plus Microdermabrasion THINGS to Try Before You Call

Things to **MAINTAIN:**



FILTERS

Blue LT Filter -

- The blue LT Filter needs to be changed after approximately 12-15 treatments.
- If the filter has been changed and the microdermabrasion machine is still not working correctly, it might be the internal filter. Please call service for further instructions.

Foam Filter -

The gray Foam Filter needs to be cleaned with *compressed air* after each treatment and is to be changed after 10 treatments.

Additional Trouble-shooting

Remove both the LT Filter and Foam Filter. With the machine on, place your finger over the hole where the filter screws in. This should let you read the maximum performance of the compressor. If the machine reading is not at least 22 Hg/inches (+/- 1) then please call service for instructions.



POOR GRAIN/CRYSTAL FLOW

Sipper Tube -

• This is most likely due to a clogged Sipper Tube.

Inside the Material Canisters are Three Metallic Tubes -

- The agitator tube in front with a gold cone
- Two sipper tubes in back
- On the short side of the coupling, you will see two set screws - one has a hole and one does not.
- Using your wire dowel that came with your machine, poke the wire end inside the hole in the set screw to loosen any debris possibly clogging the hole.
- After you have done this, insert the straw of the can of compressed air into the hole, blowing air through the opening to flush any additional debris.